



TRAV'LER® DishPRO Hybrid vs. DishPRO Plus

**DishPRO Hybrid (DPH)**

**DishPRO Plus (DPP)**



*Dual braided* coax cable connected to ports A/C

*Triple braided* coax cable connected to ports A/B/C

Receiver(s) being used



Dish® Wally®



Kit SKDPHPI is required to use more than one Wally (includes DPH Power Inserter, DISH Channel Stack splitter, and power supply)



No additional equipment is required to use Wally receivers



Dish® Hopper® 3



No additional equipment is needed to use the Hopper 3/Wireless Joys



Kit SKDPH42 is required to use a Hopper 3/Wireless Joys (includes DPH42 switch, DPH Power inserter and power supply)

Both the SKDPHPI and SKDPH42 kits can be purchased from a distributor or from Winegard directly by calling 800-288-8094.

# Quick Reference Guide

TRAV'LER®  
DishPRO Hybrid vs. DishPRO Plus



**DishPRO Hybrid**  
(DPH)



**Dual braided** coax cable  
connected to ports A/C

**DishPRO Plus**  
(DPP)



**Triple braided** coax cable  
connected to ports A/B/C

*Receiver(s) being used*



**Kit SKDPHPI** is required to use  
*more than one Wally*  
(includes DPH Power Inserter, DISH  
Channel Stack splitter, and power supply)



**Dish® Wally®**



No additional equipment  
is required to use  
Wally receivers



No additional equipment  
is needed to use  
the Hopper 3/Wireless Joeys



**Dish® Hopper® 3**



**Kit SKDPH42** is required to use a  
Hopper 3/Wireless Joeys  
(includes DPH42 switch, DPH  
Power inserter and power supply)

**Both the SKDPHPI and SKDPH42 kits can be purchased from a distributor  
or from Winegard directly by calling 800-288-8094.**